



Installation Instructions Chain Link Post /Frame Hinges



Post Male Hinge "Outside Diameter" of Post	Gate Frame Hinge "Outside Diameter" of Frame
1-3/8"	1-3/8"
1-5/8"	1-5/8"
1-7/8"	1-7/8"
2-3/8"	
2-7/8"	

- **Apply post (male) hinges to gate post.**
(To prevent gate from being lifted off, top post hinge should be installed with pin pointing down; bottom post hinge with pin pointing up.)
- **Set gate in place, aligning top of gate with top of fence.**
- **Adjust hinges to allow for full swing.**
- **Position male hinges as far apart on post as possible.**
- **Tighten all bolts securely.**



Always wear safety glasses & gloves • Thank you for your order!

"For God so loved the world, that He gave his only begotten Son, that whosoever believeth in Him should not perish, but have everlasting life." ~ John 3:16